



SAFETY FIRST!

Always close your rotary cutter when not in use - an open cutter can cause injury. Be sure to keep your cutting tools out of the reach of children.



SECRETS TO A LONGER LIFE:

Use your cutter on a good quality, self-healing mat specifically designed for sewing and quilting. To avoid chipping the blade, try not to run your rotary cutter over pins or rulers.

Your quilting and sewing scissors should only be used for cutting fabric. The exceptions to this are freezer paper or fusible web.

Do not drop your cutter or scissors as this may nick the blades.



MAINTENANCE TIPS:

Clean your cutter regularly by removing the blade, and wiping all components with a cloth moistened with a few drops of sewing machine oil. When you reassemble your cutter, don't over-tighten the screw; the blade should turn easily while cutting.

From time to time, add a drop of sewing machine oil to the screw hinge with the scissors in an open position. Wipe off any excess oil, and clean the blades at the same time.

